
AR77.20-P-0001GH	Removing and installing switch for pop-up/sliding roof	29.4.97

MODEL 163 with CODE (414a) Electric glass pop-up/sliding roof

1	*Overhead control panel*
2	*Screws*
S13/2	*Sliding/pop-up roof switch*
X18/2	*Interior/roof connector*



P77.20-0449-11

Operation no. of operation texts or of standard texts and flat rates

Division	Operation no.	Operation text
P	772650	REPLACING CONTROL SWITCH FOR SLIDING ROOF DRIVE
P	825602	REMOVING AND INSTALLING FRONT INTERIOR LAMP (1), REPLACING ACCORDING TO CONDITION

	Removal, installation		
1	Remove overhead control panel (1)		AR82.20-P-1100GH
2	Remove sliding/pop-up roof switch (S13/2) from overhead control panel control module (1)	ℹ Unscrew screws (2) from overhead control panel (1)	
3	Disconnect connector (X18/2)		
4	Install in opposite order		

